

SP3D Admin

SYLLABUS

Volume-I	Introduction
Volume-II	Admin & Project Management
Volume-III	Over View of Structured Query Language
Volume-IV	Equipment and Furnishings Reference Data
Volume-V	Piping Reference Data
Volume-VI	Structural Reference Data
Volume-VII	Electrical Reference Data
Volume-VIII	Drawing Customization
Volume-IX	SP3D Isometric Drawings
Volume-X	Report Customization (COM & SQL)

Volume-I Introduction

CHAPTER-01

1. Learning about Smart Plant Administrative Functions in the Software
2. Common Overview
3. Types of Database
4. Overview of Symbol share

Volume-II Admin & Project Management

CHAPTER-01

1. Create new site and plant
2. Create permission groups and assign permissions
3. Simple Backup
4. Restoring a Plant Database (Option 1)

5. Restoring a Plant Database (Option 2)

6. Restoring a Plant Database (Option 3)

7. Deleting a Plan

8. Deleting a Catalogue

CHAPTER-02

9. Manual Creation of System Hierarchy

10. Import Creation of System Hierarchy

11. Assign Specifications to Systems

12. Restore as copy Training Plant

13. Model Data Reuse Copy – Move in Existing Plant

14. Model Data Reuse Copy – Rotate and Copy to New Plant

CHAPTER-03

15. Synchronize Model with Catalogue and View Generation

16. Database Maintenance

17. Database Integrity

18. Error log files

19. Interference Checking

20. Export ZVF and XML files to be used in R3D referencing

21. Attach external 3D data as a reference (R3D)

22. Perform transformation (rotation, scaling, and translation) to R3D models

23. Update attached R3D models

CHAPTER-04

24. Export VUE and MDB2 files to be used for R3D Referencing

25. Use R3D referenced models for Parallel Design (Optional)

26. Bulk load Reference Data

SP3D Admin

Volume-III Over View of Structured Query Language

CHAPTER-01

1. SQL Database Maintenance
2. Back Up and Restore
3. Catalogue Data Recovery for SQL Server 2014 SP3
4. Host Failure and Recovery
5. Permission Groups

Volume-IV Equipment and Furnishings Reference Data

CHAPTER-01

1. What's New in Equipment and Furnishings Reference data
2. Catalogue u Hierarchy CHAPTER-02
3. Equipment Catalogue u Hierarchy
4. Custom Interface Sheet

Volume-V Piping Reference Data

CHAPTER-01

1. Creating a New Piping Materials Class
2. Adding a New Piping Component to a Specification

CHAPTER-02

3. Adding a New Part to the Catalogue
4. Piping Specification Rules

CHAPTER-03

5. Create New Piping Part Classes using Bulk load
6. Bolt Part Data Sheet

Volume-VI Structural Reference Data

CHAPTER-01

1. Structural
2. Reference Data Overview
3. Member Reference Data
4. Define a New Member Type
5. Define a New Material Type

CHAPTER-02

6. Struct Assembly Connections Workbook
7. Slabs, Walls, and Openings Reference Data
8. Export user-defined attributes from Tekla Structures

Volume-VII Electrical Reference Data

CHAPTER-01

1. Electrical Reference Data
2. Naming Rules Reference Data
3. Electrical Reference Data Workflow
4. Cableway Reference Data
5. Cable Tray Reference Data

CHAPTER-02

6. Duct Bank Reference Data
7. Conduit Reference Data

Volume-VIII Drawing Customization

CHAPTER-01

1. Import a Border File and Create a Drawing Area
2. Reference Data Tools
3. Define View Style Command
4. View Style Properties Dialog Box

SP3D Admin

5. Create an Orthographic Drawing View Style

3. Advanced Reporting

CHAPTER-02

6. Edit Border Template Command

7. Edit Layout Template Command

8. Add Flow Arrows to Orthographic Drawings

CHAPTER-03

9. Creating & Updating Drawings

10. Drawing Editor

11. Smart Labels

CHAPTER-04

12. Drawing Types (Snapshot, Volume & Drawings by Query)

13. Document Status Icons

Volume-IX SP3D Isometric

Drawings

CHAPTER-01

1. Introduction

2. Isometric drawings extraction

3. Importing Micro station DGN or DWG Border file

CHAPTER-02

4. Create Package

5. Run Query (Shortcut Menu)

6. Isometric Drawing Styles

Volume-X Report Customization

(COM & SQL)

CHAPTER-01

1. Creating Model Reports

2. Defining a COM Label